

Maintenance and Storage of Rollers and Fibreglass Sleeves Covered with Elastomeric Compounds

- * Do not store resting on the surface.
- * Rollers should be stored supported only on the journals.
- * Fibreglass sleeves should always be stored in an upright but secured position.
- * Do not store under high temperature or high humidity conditions.
- * Do not stack or rest anything against the covered surface.
- * Avoid direct UV rays on the surface.
- * Do not allow any chemicals to come in contact with the surface other than the recommended ones.
- * Do not soak rollers or sleeves for cleaning, even using recommended solutions.
- * Do not allow any inks or glue to dry on the surface.
- * Do not apply any pressure on a stationary roller or sleeve.
- * Air used for f/g sleeves should have a pressure of 6-8bar and a min. flow of 12 litre/sec.
- * Do not fit the sleeve by hitting or using extreme force.
- * Always clean the inside surface of the sleeve and outside of the air mandrel before fitting a sleeve on the mandrel.
- * Inspect the airholes of the mandrel, ensuring they are not blocked or restricted
- * Do not cut the rubber or the sleeve
- * To ensure a permanent conductivity of conductive sleeves do not apply isolation materials like varnishes or any other additional layers as they have a negative effect on the conductivity.
- * Conductive sleeves are design to discharge electrostatic charges through the sleeve.
- * Conductive sleeves are normally manufacture with a resistance R≤10 $^{\circ}$ Ω.